

Eggtimer WiFi Device Connection Tips

1. After you turn on your WiFi Switch or arm your Eggtimer WiFi altimeter, CLOSE the browser, and go to your Settings and turn OFF WiFi on your phone. This does wonders... believe me.
2. Make sure you're in Private (Apple) or Incognito (Android) mode... you don't want it saving the pages and caching it later.
3. The ONLY shortcut you should save is the Home page URL... <http://192.168.4.1> . DO NOT save any URL with anything after the IP address unless it's explicitly stated in the documentation (which you did read, right?)
4. DO NOT use the back arrow for any Eggtimer WiFi pages. We disable caching on the pages, but it's up to the device to enforce that... and they do not always do it. We always put a Back link at the bottom of the page if you want to exit a page.
5. If your phone gives you a popup telling you that you don't have Internet connectivity, tell it to KEEP the WiFi connection, and DO NOT switch to cellular data.
6. If you use a VPN for security, turn it off while you're connected to the Eggtimer WiFi devices. You can't get on the Internet to use it anyway.
7. If all else fails, turn off cellular data on your phone while you're using your Eggtimer WiFi devices.